Container PMT Testing Data in ROOT format

Email: zhaor25@mail2.sysu.edu.cn

School of Physics





troduction calibration of drawe

introduction

- 1 Onsite server:login.pmt.ihep.ac.cn
- 2 raw testing data path: /pmtfs/disk01/container_data/Meassurements_DAQ
- 3 output ROOT file path: /pmtfs/disk01/container_data/rawdata
- 4 file size: about 500Mb for one PMT each test.
- 5 name rule: container+drawer+SN

¹https://juno.ihep.ac.cn/mediawiki/index.php/Onsite computing/IT

inside one ROOT file

One can get 13 trees and one TObject "Pmtdata" from the ROOT file

```
sys1_mass10410_channel123_snPA1901-1069.root
            gainm150;1 PA1901-1069_tree2
            gainm0;1 PA1901-1069_tree5
KEY: TTree DCR;1 PA1901-1069_tree10
```

TObject:Pmtdata

The custom class "Pmtdta" is inherited from TObject, and it store the auxiliary information of one pmttest such as: SN,test-date,HV,base .etc.

```
TString pmt_id=thispmt->Getsn();
TString test date=thispmt->Gettestdate();
int uid=thispmt->Getuid():
int fit_HV=thispmt->Getchv();
double cont dcr=thispmt->Getdcr();
int pmtnum=thispmt->Getpmtnum();
int umassnum=thispmt->Getumassnum();
int base type=thispmt->Getbasetype():
int pmt type=thispmt->Gettype():
int vendor HV=thispmt->Getvhv();
double vendor ge=thispmt->Getvge():
double vendor_ap=thispmt->Getvap();
double vendor dcr=thispmt->Getvdcr();
double vendor rt=thispmt->Getvrt():
double vendor_ft=thispmt->Getvft();
double vendor pvr=thispmt->Getvpv():
double vendor_res=thispmt->Getvres();
```

waveform data

There are 11 trees for the storage of testing waveform:


- mu1peo with the LED light intensity @ $\mu \simeq 1$.
- mup1pe \rightarrow with the LED light intensity @ $\mu \simeq 0.1$.
- gain... \rightarrow with the LED light intensity @ $\mu \simeq 0.1$ and HV=vendor HV+{-150V,-100V,-50V,0V,50V,100V,150V}.
- TTSdata → waveforms for TTS test.
- TTStrig→ waveforms for the trig signals of TTS test.

Each waveform is a "TVector" with length 500, and the value is in mV unit.

Also, the "DCR" tree is for dark count rate data and "AP" tree is for afterpulse data. The values are accumulated DCRs with 1s step.

simple test for the ROOT file

read the TTS and mu1pe waveform from ROOT:



summary

- The waveform raw data and auxiliary testing information can be stored in one ROOT file.
- one can easily access all the raw data for one specific test through ROOT.
- If we convert all testing data, the disk space required is about 15TB.

Back-Up

load the Pmtdata class

```
to use the shared library:
CINT mode: gSystem-
>Load("/home/pmthome/zhaor/zhaorong/cont_v1/pmttest_cc.so");
in script:
R_LOAD_LIBRARY(/home/pmthome/zhaor/zhaorong/cont_v1/
pmttest_cc.so):
```